



Rise and Fly

Design courtesy of Bisque Imports

Enjoy your morning coffee in this lovely butterfly mug!

MATERIALS

413 Super Mug
8012 3/4" Art Tape
BSS-6 Butterflies Silk Screen
CMC2oz Glaze Thickening Powder
CN012-8 Bright Straw
CN042-8 Bright Papaya
CN253-8 Dark Black
CN351-8 Light Sapphire

SUPPLIES

Assorted Royal Aqualon Brushes
Pallet Knife
Scissors
Water
Tape
Water

INSTRUCTIONS

1. Lightly wipe ware with a damp sponge to prepare surface for painting.
2. Cut out the silkscreen, leaving a wide border around the image outline. Position the silk screen onto the mug surface so that the image lays completely flat. Use 3/4" Art Tape to secure the silk screen to the bisque surface.
3. On your pallet, pour a dime-sized drop of Dark Black. Add a pinch of Glaze Thickening Powder to the underglaze color, then mix using a pallet knife until you reach a peanut butter consistency.
4. Dip your finger in the thickened underglaze color, and rub the color into small areas of the screen image at a time. Dab and smooth the paint into the screen until all areas are filled with color.
5. Once completed, gently lift and remove the silk screen and art tape. Immediately rinse the silk screen off to remove any glaze.
6. Paint the inside of the mug with 3 coats of Light Sapphire.
7. Paint the handle with 3-4 coats of Bright Papaya.
8. Brush on 1 coat of Bright Papaya over each top wing.
9. Brush on 1 coat of Bright Straw over each bottom wing.
10. Brush on 1 coat of Light Sapphire over the body.
11. Let dry. Dip in Pure Brilliance and fire to Cone 06.