



Flower Frenzy

Design courtesy of Bisque Imports

The Crafter's Workshop stencils make great frit stencils!

MATERIALS

Assorted Carolina Frit - Fine
GBS10-100 10 In. Square Clear Transparent
GBS10-200 10 In. Square White Opalescent
SM9504 Jumpin' Jack Mold
SP-8234 Glas Tac
TCW157 Flower Frenzy - 12" X 12" Template

SUPPLIES

Detail Brush
Hairspray
Plastic Spoon
Toothpick
Water

INSTRUCTIONS

1. Lightly spritz the White Opalescent glass blank with hairspray to give the surface tackiness.
2. Position the stencil flat onto the glass base.
3. Apply an even layer of assorted fine Carolina Frit over the stencil design areas using a small plastic spoon.
4. With the stencil still in place, apply pinpoint of Glas Tac to secure the frit within the open design areas.
5. Very gently lift the stencil from the glass base, ensuring the frit design areas stay intact.
6. If needed, use a toothpick or a small paintbrush to touch up any design areas. Allow project to dry completely.
7. Cap the project with a sheet of Clear Transparent.
8. Full fuse using Spectrum's 6-segment firing schedule.
9. Once fired, slump project in the Jumpin' Jack Mold.