



Coffee-Tie-Go

Design courtesy of Bisque Imports

Now Dad can carry his love with him wherever he goes!

MATERIALS

28550 Joe to Go
CN201-8 Light Grey
CN253-8 Dark Black
CN511-8 Sunflower Yellow

SUPPLIES

Assorted Royal Aqualon Brushes
Detail Brush
Pop-Up Sponge
Scissors
Sharpie
Water

INSTRUCTIONS

1. Lightly wipe ware with a damp sponge to prepare surface for painting.
2. Draw a tie approximately 3.5" long on a pop-up sponge, then cut it out.

3. Paint inside of mug with 2-3 coats Dark Black.

4. Dip tie sponge in water so it expands;. Squeeze out excess water,

5. Starting on the left side, close to the handle, dip the tie sponge into Sunflower and gently press onto your mug. Rotate the sponge 180 degrees so the tie is upside down. Repeat all the way around the mug stamping vertically. If your tie extends beyond the edge of the mug, it's okay.

TIP: Practice pressing your sponge on a piece of paper or tile before applying it onto bisque so you can determine the right amount of pressure for the look you want.

6. Paint handle of mug with 2-3 coats of Light Grey.

7. Using a detail brush and Dark Black, outline ties, add patterns and accents.

7. Use a sponge and water to clean up any unwanted paint on the rim of the mug.

8. Dip in Clear Brilliance and fire to Cone 06.